



Remove the contactor from the control and replace it with the new 110v contactor. except the incoming line. Ensure incoming line continues to go to pins 2 and 3 of the power connector on the printed circuit board. The new 220v incoming line goes to the line side of the contactor.

Electronic Machine Parts	
File	SERVO CIRCUIT BOARD A5
Size	Document Number
C	
Date	Monday, January 03, 2005
Sheet	1 of 1
Rev	A